

4 Inches

7 3/4 Inches

**1.** Cut out 1 piece of front fabric and 1 piece of back fabric, placing fabric fold at the FOLD line.

**2.** Sew pieces, right-sides together, with a 1/4" inseam leaving a 2" opening along 1 straight edge to turn.

**3.** Turn and top-stitch, making sure to sew your opening closed.

Fabric Fold

